OWNER & SERVICE MANUAL

SPARTAN Self-Leveling System

- 7

H00700ES20 H00700ET25 H00700ET35 H00700ET40 H00700ET41 H00700ET415 H00700ET495

Link Mfg. Ltd. 223 15th St. N.E. Sioux Center, IA USA 51250-2120 www.linkmfg.com

Control

QUESTIONS? CALL CUSTOMER SERVICE 1-800-222-6283

1. INTRODUCTION

Thank you for choosing a Link Smart Air Management System. We want to help you get the best results from this height control system and to operate it safely. This instruction contains information to assist in owning and servicing of the Smart Air Management System. This instruction is intended solely for use with this product.

All information in this instruction is based on the latest information available at the time of printing. Link Manufacturing reserves the right to change its products or manuals at any time without notice.

Damaged components should be returned to Link with a pre-arranged Returned Materials Authorization (RMA) number through the Customer Service Department. The damaged component may then be replaced if in compliance with warranty conditions.

2. SAFETY SYMBOLS, TORQUE SYMBOL, and NOTES

A DANGER	DANGER indicates a hazardous situation which if not avoided, will result in death or serious injury.
	WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	CAUTION indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE	<i>NOTICE</i> indicates a potentially hazardous situation which, if not avoided, may result in property damage.
	<i>TORQUE</i> indicates named fasteners are to be tightened to a specified torque value.
NOTE:	A Note provides information or suggestions that help you correctly perform a task.

3. SAFE WORKING PRACTICES

3.1

ACAUTION

When handling parts, wear appropriate gloves, eyeglasses, ear protection, and other safety equipment.

3.2

When towing, jacking, or raising the vehicle for service, power must be removed from the SLS system by turning the ignition switch to the "OFF" position. This will prevent the SLS system from operating and eliminating the potential for unexpected suspension movement that may cause damage to the vehicle or result in personal injury.

3.3

AWARNING

The use of the Air Leveling System for overnight parking is not recommended. Hydraulic jacks should be utilized for overnight parking.

3.4

NOTE

If the vehicle is equipped with a hydraulic leveling system, the hydraulic operation will override the air system. It will control the air system operation as required in order to provide the desired hydraulic leveling action.

4. SYSTEM SCOPE

4.1

The Self Leveling System is designed for this application to maintain a predetermined vehicle ride height automatically and provides a means to manually lower or raise the ride height through a customized user interface. The system provides for side to side height control as well as front to back control. The system also contains a feature to determine if the vehicle is on a surface that will enable the chassis to be leveled within vehicle mechanical parameters. A visual indication is also provided to determine mode selection and system malfunction detection.

5. SYSTEM DEFINITION

5.1

The Self Leveling System (SLS) contains four vehicle height sensors, a pneumatic manifold assembly, an electronic control unit (ECU), the necessary wire harnessing, a pushbutton control user interface, and the necessary vehicle interface hardware to provide the defined modes of operation and system functionality. The user interface contains the required pushbuttons to allow the vehicle operator to raise and lower the vehicle manually, enable a self-leveling feature to level the vehicle when parked on an uneven surface, and contains LED's (light emitting diodes) to provide a visual indication to the vehicle operator of the manual mode status, as well as system error detection. The location and mounting of the user interface will be to the user's discretion. The angle sensors will be mounted on the vehicle frame in a 4-point configuration: rear (2); front (2). The wire harnessing will provide the necessary connections for providing DC electrical control power and ground to the SLS system (from a suitable vehicle power source), provide the necessary height sensor connectors, provide the pneumatic manifold wiring interface, provide the necessary color coded wires for vehicle hardware integration, and provide the electrical connections for the user interface. Functionally, the system will provide the following modes of operation, i.e. standard ride, raised, lowered, and self-leveling. This information is further defined in the following sections.

6. STANDARD RIDE MODE

6.1

This mode of operation occurs automatically. It requires no further interaction by the vehicle operator. The ECU monitors the feedback signals from the height sensors during normal vehicle operation. Should any of the four signals dictate that the vehicle is above or below the programmed ride height; the ECU will energize the necessary manifold valve coils to either fill or exhaust the respective air spring(s) to bring the system back to the correct ride height.

6.2

The system will stay in this mode of operation unless conditions are satisfied to enter the other modes of operation, as defined in the following sections. However, should one of the other modes of operation be selected, the ECU will automatically return the vehicle to this mode when the vehicle exceeds the maximum speed limitation defined in the system program (see following modes of operation), the complimentary mode pushbutton located on the user interface is momentarily depressed, or the "standard ride" pushbutton located on the user interface is momentarily depressed.

6.3

The LED located above the pushbutton on the user interface will come "ON" whenever the STD Ride pushbutton has been depressed to provide a visual indication of the action. Should the system be in another mode of operation when the pushbutton is depressed and released or whenever an auxiliary control returns the system to the standard ride mode, the LED located above the STD Ride pushbutton will "flash" while the system is returning to the standard ride height. Once the standard ride height is reached, the LED will come "ON" steady for about 15 seconds and then it will go "OFF". This provides a visual indication the system has returned the vehicle ride height to within limitations.

6.4

When power is applied to the system and the vehicle is in the *standard ride mode* and the vehicle is at the standard ride height, the LED located above the STD Ride pushbutton will come "ON" steady for about 15 seconds and then it will go "OFF". This provides a visual indication the ECU has checked and verified the vehicle ride height is within limitations.

6.5

When power is applied to the system and the vehicle is in the *standard ride mode* but the vehicle is not at the standard ride height, the LED located above the STD Ride pushbutton will "flash" while the system makes the necessary adjustments to return to the vehicle to the standard ride height. Once the system has reached the standard ride height, the LED located above the STD Ride pushbutton will come "ON" steady for about 15 seconds and then it will go "OFF". This provides a visual indication the ECU has checked and verified the vehicle ride height is now within limitations.

6.6

ACAUTION

When towing, jacking, or raising the vehicle for service, power must be removed from the SLS system by turning the ignition switch to the "OFF" position. This will prevent the SLS system from operating and eliminating the potential for unexpected suspension movement that may cause damage to the vehicle or result in personal injury.

7. RAISED MODE

7.1

This mode of operation is used to *increase* the clearance between the underside of the vehicle frame and the ground surface. The vehicle operator must select this mode of operation and choose to raise either the rear only of the vehicle or to raise the entire vehicle. A separate action must be performed by the vehicle operator in order to initiate either function of the *raised mode* of operation. This action is further discussed in the following two paragraphs.

7.2

Raising the rear only of the vehicle can be chosen by the vehicle operator to increase the clearance between the rear bumper of the vehicle and the ground. It may be necessary for the operator of the vehicle to select this mode when situations arise where the rear of the vehicle may drag due to the length of the vehicle and the departure angle. This mode may be selected by momentarily depressing the "raise" pushbutton located on the user interface, with the vehicle speed at 20MPH or less. Once the mode is selected, the system ECU will temporarily raise the rear of the vehicle and the LED located above the pushbutton on the user interface will blink as a visual indication the mode has been activated.

7.3

The ECU will automatically return the rear of the vehicle to the normal ride height when the speed exceeds 20MPH, the mode has been active for more than 40seconds, the operator momentarily depresses the "lower" pushbutton located on the user interface, or the operator depresses the "standard ride" pushbutton located on the user interface. Once the mode has been deactivated, the ECU will automatically turn off the LED.

7.4

Raising the entire vehicle can be chosen by the vehicle operator to increase the clearance between the entire vehicle and the ground. It may be necessary for the operator of the vehicle to select this mode when situations arise where the body of the vehicle must be raised to avoid or to overcome an undercarriage obstacle. This mode may be selected by depressing and holding the "raise" pushbutton for approximately 3 seconds, with the vehicle speed at 10MPH or less. The pushbutton must be held until the LED located above the pushbutton remains on continuously. At that point, the pushbutton can be released and the mode will remain active. Once the mode becomes active, the system ECU will raise the entire vehicle and the LED located above the pushbutton will remain on as a visual indication the mode is active.

7.5

The ECU will automatically return the entire vehicle to the normal ride height when the speed exceeds 10MPH, the operator momentarily depresses the "lower" pushbutton located on the user interface, or the operator depresses the "standard ride" pushbutton located on the user interface. Once the mode has been deactivated, the ECU will automatically turn off the LED.

7.6

NOTE

If the vehicle is equipped with a hydraulic leveling system, the hydraulic operation will override the air system. It will control the air system operation as required in order to provide the desired hydraulic leveling action.

8. LOWERED MODE

8.1

This mode of operation is used to decrease the clearance between the underside of the vehicle frame and the ground surface. The vehicle operator must select this mode of operation and choose to partially lower or entirely lower the whole vehicle. A separate action must be performed by the vehicle operator in order to initiate either function of the lowered mode of operation. This action is further discussed in the following two paragraphs.

8.2

Partial lowering of the vehicle ride height can be chosen by the operator of the vehicle to decrease the clearance between the vehicle and the ground, to a predetermined position, in order to clear an overhead obstruction. This mode may be selected by momentarily depressing the "lower" pushbutton located on the user interface, with the vehicle speed at 10MPH or less. Once the mode is selected, the system ECU will lower the entire vehicle to a predetermined position and the LED located above the pushbutton on the user interface will blink as a visual indication the mode has been activated.

8.3

The ECU will automatically return the entire vehicle to the normal ride height when the speed exceeds 10MPH, the operator momentarily depresses the "raise" pushbutton located on the user interface, or the operator depresses the "standard ride" pushbutton located on the user interface. Once the mode has been deactivated, the ECU will automatically turn off the LED.

8.4

Entire lowering of the vehicle ride height can be chosen by the operator of the vehicle to further decrease the clearance between the vehicle and the ground to a mechanical minimum distance in order to allow additional clearance for an overhead obstruction. This mode may be selected by depressing and holding the "lower" pushbutton for approximately 3 seconds, with the vehicle speed at 5MPH or less. The pushbutton must be held until the LED located above the pushbutton remains on continuously. At that point, the pushbutton can be released and the mode will remain active. Once the mode becomes active, the system ECU will lower the entire vehicle to the lowest possible mechanical position and the LED located above the pushbutton on the user interface will remain on as a visual indication the mode is active.

8.5

The ECU will automatically return the entire vehicle to the normal ride height when the speed exceeds 5MPH, the operator momentarily depresses the "raise" pushbutton located on the user interface, or the operator depresses the "standard ride" pushbutton located on the user interface. Once the mode has been deactivated, the ECU will automatically turn off the LED.

8.6 NOTE

The illustration below summarizes the raise and lower operation with relation to the respective user interface pushbuttons and indicators.

RAISE Button

Press once to raise the rear of the vehicle for increased bumper clearance. (The Raise light flashes) [Speed < 20 MPH]

or

Press and hold button until raise light remains "on" to raise entire vehicle for increased ground clearance. [Speed < 10 MPH]

Press "LOWER" switch once or "STD RIDE" switch once to return vehicle to normal height. (Raise light off)

LOWER Button

Press once to partially lower the vehicle to decrease overall height. [Speed < 10 MPH] (The Lower light flashes)

or

Press and hold button until the lower light remains "on" to lower the vehicle to lowest overall height. [Speed < 5 MPH]

Press "RAISE" switch once or press "STD RIDE" switch once to return to normal height. (Lower light off)

8.7

NOTE

If the vehicle is equipped with a hydraulic leveling system, the hydraulic operation will override the air system. It will control the air system operation as required in order to provide the desired hydraulic leveling action.



STD RIDE Button

Press this button to return the vehicle to the "standard ride height", regardless of mode operation.

The STD Ride light will come "on" whenever the STD Ride button is depressed or whenever an auxiliary control returns the system to the standard ride mode.

or

The STD Ride light will "flash" while the system is returning to the Standard Ride height from any mode of operation. Once the Standard Ride height is reached, the light will come "on" steady for about 15 seconds and it will then go "off".

or

When power is applied to the system and the vehicle is in the STD Ride mode and the vehicle is at the standard ride height, the light will come "on" steady for about 15 seconds and it will then go "off".

or

When power is applied to the system and the vehicle is in the STD Ride mode, but the vehicle is not at the Standard Ride height, the light will "flash" while the system makes the necessary adjustments to return to the Standard Ride height. Once the Standard Ride height is reached, the light will come "on" steady for about 15 seconds and then it will go "off".

9. SELF-LEVELING MODE

9.1

This mode of operation is two-fold. First, it can be used to evaluate perspective vehicle parking areas to ensure the vehicle can be adjusted to be within leveling parameters for maximizing occupant comfort (*level find mode*). Second, once a suitable parking area is found, it is used to automatically level the suspension of the vehicle, even though the parking area may be an uneven surface (*self leveling mode*). The following paragraphs further explain this mode of operation.

9.2

The "SLS" pushbutton, located on the right hand area of the user interface is used to initiate the self leveling mode. This pushbutton serves as the "ON" switch to begin the entire self leveling process. When the SLS pushbutton is depressed and the vehicle is operating at slow speed (typically 5MPH or less), the ECU will begin the level find mode. This is an evaluation process, whereas the system ECU will look at the signals received from the four height sensors and the signals from the two inclination sensors. The height sensors will provide the ECU with real time information on the location of each corner of the vehicle in reference to the normal ride height. At the same time, the inclination sensors will provide real time information to the ECU on the location of the "X" and "Y" axis of the vehicle in relation to the reference horizontal position. The ECU will perform the necessary comparisons and determine if the vehicle is capable of being leveled at the particular location. The ECU will provide a visual indication of this process to the vehicle operator by turning on the indicator arrows located to the left of the SLS pushbutton.

9.3

The two arrows reference the "X" and "Y" axis of the vehicle. The top arrow, (points left to right) represents the "X" vehicle axis (short axis – side to side) and the bottom arrow (points top to bottom) represents the "Y" vehicle axis (long axis – front to rear). The arrows will be "flashing" or "ON" solid and be either an amber or green color. The four combinations of light status and color can be interpreted by the following information:

- Solid Green the vehicle is near level
- Flashing Green Adjustment is possible and within range
- Flashing Amber Adjustment is marginal
- Solid Amber Self Leveling May Not Be Possible (Excessive Slope)

Once activated, the system will remain in the level find mode until the "SLS" pushbutton is depressed a second time or the "STD RIDE" pushbutton is momentarily depressed.

9.4

When the level find mode is complete, the operator can proceed to initiate the self leveling part of the process. To initiate this process, the SLS pushbutton must first be depressed (this may have already been performed if the vehicle operator used the *level find mode*).

- The vehicle must be stopped, placed in park, the parking brake applied, and then the "SET" pushbutton is depressed. (Note: If the parking brake is not applied, the self leveling process will not be allowed to occur by the system ECU).
- Once the *self-leveling* mode is activated, the LED located above the "SET" pushbutton will flash as a visual indication the mode is active. The ECU will first adjust the vehicle "Y" axis and then the "X" axis.
- Once the leveling process is complete, the LED located above the "SET pushbutton will be "ON" continuously.

9.5

Once activated, the system will remain in the *self leveling* mode until either the "SET" pushbutton is depressed a second time, the vehicle parking brake is released, or the "STD RIDE" pushbutton is momentarily depressed.

9.6

NOTE

Figure 2 on the following page summarizes the "level find" and "self leveling" operation with relation to the respective user interface pushbuttons and indicators.

9.7

NOTE

If the vehicle is equipped with a hydraulic leveling system, the hydraulic operation will override the air system. It will control the air system operation as required in order to provide the desired hydraulic leveling action.



10. POWER LOSS RECOVERY

10.1

This is a programmable feature which allows the SAMS ECU to "remember" the mode of operation that was active, in the event of a system power loss. The ECU stores this data automatically and then will continue the same mode of operation at a later time, when power has been restored. This provides for predictable system operation and reliable system control.

10.2

This function holds true in the event the vehicle operator turns "OFF" the ignition of the vehicle. Turning "OFF" the ignition removes power to the SLS system. This prevents draining the vehicle battery by operating the fill/exhaust valves without the engine running and the vehicle charging system in operation. Should the SLS system be in either the raised mode or the lowered mode when the ignition is turned "OFF", the ECU will retain the active mode status, and return the system to the active mode upon starting the vehicle. The active mode will continue unless it becomes cancelled by one of the appropriate means described in the respective section discussed earlier in this document.

11. VISUAL INDICATORS

11.1

As explained in earlier sections of this document, if either the raised mode (rear only) or lowered mode (partial) is selected, the respective pushbutton LED will flash. Additionally, if the raised mode (entire vehicle) or lowered mode (lowest possible mechanical position) is selected the respective LED will be "ON" continuously. The user interface also contains a suspension and an air pressure indicator. Should the system ECU detect a problem, the suspension light will blink in such a manner as to identify an error code associated with the fault. Additionally, should the system air pressure fall below 95psi, the system ECU will illuminate the air pressure indicator, system will be inactive until air pressure reaches sufficient pressure for proper operation.

11.2 NOTE

The following section provides more information regarding the specific system error codes.

12. ERROR CODES

12.1

The ECU has the ability to monitor the SLS system and detect electrical problems. Should the ECU detect a problem, a visual indication will be given by flashing the suspension indicator located on the user interface panel in such a manner as to represent a two or threedigit code. The first number of the code can be identified by counting the first series of flashes. It will be followed by a short pause, and then provide a second series of flashes to represent the second number of a two-digit code (if applicable, the second number will be followed by another short pause, and then provide a third series of flashes to represent a three-digit code).

For example one flash, followed by a short pause, and then two additional flashes would illustrate a code 12.

12.2

In the event of more than one detected problem, the ECU will cycle through this process and flash an individual error code for each identified problem. The ECU will continue to flash the error code(s) until the problem(s) have been corrected. Once the problem(s) are corrected, the ECU will proceed to turn off the suspension indicator.

12.3

A list of potential error codes and their probable cause are as follows:

- 11 (eleven) -
- Rear Drive, Driver Height Sensor Rear Drive. Curb Height Sensor 12 (twelve) -
- 14 (fourteen) -ECU Sensor Reference Voltage
- 24 (twenty-four) -
 - X Axis Inclination Sensor
- Y Axis Inclination Sensor 31 (thirty-one) -

32 (thirty-two) -Front, Driver Height Sensor Front, Curb Height Sensor 33 (thirty-three) -34 (thirty-four) -Supply Pressure Transducer 41 (forty-one) -Invalid Battery Voltage 42 (forty-two) -Not Used 43 (forty-three) -Low Battery Voltage (less than 9.7 VDC) High Battery Voltage 44 (forty-four) -(greater than 14.8VDC) 111 (one hundred eleven) - Front, Driver Exhaust Solenoid Valve 112 (one hundred twelve) - Front, Driver Fill Solenoid Valve 113 (one hundred thirteen) - Front, Curb Exhaust Solenoid Valve 114 (one hundred fourteen) - Front, Curb Fill Solenoid Valve 121 (one hundred twenty-one) – Rear Drive, Driver Exhaust Solenoid Valve 122 (one hundred twenty-two) – Rear Drive, Driver Fill Solenoid Valve 123 (one hundred twenty-three) - Rear Drive, Curb Exhaust Solenoid Valve 124 (one hundred twenty-four) - Rear Drive, Curb Fill Solenoid Valve 213 (two hundred thirteen) - Valve Manifold Connector 1 (Male) Disconnected 214 (two hundred fourteen) – Valve Manifold Connector 2 (Female) Disconnected 333 (three hundred thirty-three) - CAN bus Data Not Read

12.4 NOTE

The following illustration summarizes the system warning lights with relation to the respective user interface indicators.



Air Pressure Indicator

This indicator will flash when the air pressure is insufficient to properly operate the air suspension control system.

Figure 3

13.SLS MANIFOLD & VALVES

14. THEORY OF OPERATION

13.1

This section is written to provide an introduction to the manifold and valves used on Spartan's Self Leveling System (SLS). This discussion will create a basic understanding of the valve functionality.

The knowledge gained by understanding the document content will provide service personnel with information to diagnose and repair related system problems.

14.1

The manifold is an electro-pneumatic device used to control the air flow within the SLS system. The valves are two-position and of a coil actuated design. This application requires two valves per air spring for ride height control, totaling eight (8) valves in all. One valve serves as a "fill" valve and allows system air to pass through the manifold "into" the air spring. This causes the air spring to inflate, thereby increasing the vehicle ride height. The second valve serves as an "exhaust" valve and allows air to pass "from" the air spring, through the manifold, into the atmosphere. This causes the air spring to deflate, thereby decreasing the vehicle ride height.



14.2

The valves are controlled by the SLS electronic control unit (ECU). The ECU provides the brains for the Self Leveling System. The ECU contains the system specific program to control the vehicle ride height, as defined by Spartan's engineering specifications for system operation. The ECU receives signals from various system components, i.e. height sensors, pressure transducers, inclination sensors, and the user control panel (mode of operation) to provide system control for obtaining the desired vehicle ride height.

14.3

With no power applied to the valve coils, they are in a de-energized condition. This allows an internal spring to expand and pushes a plunger against the associated manifold port, thereby sealing off the internal air passage. The face of the plunger also contains a seal that when forced against the seat of the manifold, provides a positive seal to prevent air flow through the manifold when the valves are de-energized. This mechanical action enables the SLS system to seal the air within the system and maintain the desired ride height.

14.4 NOTE

The ports of the manifold contain a mesh screen to help prevent air contaminates from entering the manifold. However, it is possible for the screen to become damaged and allow contaminates to enter the manifold. Should this occur, it is possible for debris to collect on the plunger face seal or cause the plunger to stick open, thereby affecting system operation and performance.

14.5

Should an inflation valve plunger become contaminated or the plunger stick "open", it is possible for air to leak past the plunger and continuously fill the associated air spring. This would cause a corner of the vehicle to continuously creep "upwards" while the vehicle is in operation, and result in the SLS system constantly making corrections to lower the affected corner of the vehicle.

14.6

Should an exhaust valve plunger become contaminated or the plunger stick "open", it is possible for air to leak past the plunger and continuously exhaust the associated air spring. This would cause a corner of the vehicle to continuously creep "downwards" and result in the SLS system constantly making corrections to raise the affected corner of the vehicle. It should be noted that this condition would be most noticeable after the vehicle has not been in operation for a period of time because the respective corner of the vehicle would lean.

14.7

NOTE

An external leak, such as a loose air fitting, defective air spring, or tube leak could also cause the vehicle to lean when not in operation for a period of time. External leaks can be detected by squirting a suitable inspection solution, i.e. soap, water, & glycerin mix onto the external system components. If an air leak is present, air bubbles will be created in the applied solution.

14.8

If either of these conditions is noticed, the vehicle should be inspected and the cause of the problem corrected. These conditions could eventually cause premature compressor failure due to overheating from excessive cycling. The compressor would attempt to maintain system pressure that would continuously fluctuate due to the ECU trying to compensate for the system problem.

14.9

When it becomes necessary to either raise or lower the vehicle ride height, the ECU will energize the respective manifold valve coil(s) by applying 12 VDC. With 12 VDC applied to the coil, current flows through the windings and creates an electro-magnetic field. This magnetic field is stronger than the existing spring pressure that holds the valve plunger against the valve seat within the manifold. The strength of the magnetic field will cause the plunger to move inside the body of the valve assembly, compressing the spring, and opens the respective "fill" or "exhaust" passage within the manifold. This will allow system air to either "fill" or "exhaust" the associated airspring. This action will either raise or lower the vehicle, depending upon which valve has been energized. When the desired position has been reached, the ECU will remove power from the valve coil(s), the internal spring will decompress (expand), and the plunger will once again seal off the associated manifold port. This sealing action will sustain the desired ride height until system adjustment once again becomes necessary.

15. VALVE SERVICING

15.1

The valves are secured to the body of the manifold by using three (3), 10-32 X 5/8" stainless hex socket screws and are factory tightened to 25in/lbs. of torque. Care must be taken when removing or replacing the valve assembly so as not to lose the mounting hardware or the O-ring that is installed. The O-ring and mounting hardware create a positive seal between the valve assembly mounting plate and the valve mounting surface of the manifold.

15.2

NOTE

If the O-ring is lost or damaged or the valve is not properly attached to the manifold by using all of the previously mentioned hardware, an external leak will occur and a source for contamination to enter the manifold is created.

The solenoid replacement kit number is H16902S.

15.3

AWARNING

System operating pressures are typically 95-130psi. Steps should be taken to relieve pressure from the system prior to removing any valve assembly from the manifold.

15.4

NOTE

Prior to disconnecting the manifold wiring harness to perform the continuity check, be sure power has been removed from the SLS system ECU. This can be accomplished by turning the ignition switch to the "OFF" position. This prevents the SLS system from operating when the engine is not running, which could result in unanticipated suspension movement.

16. MANIFOLD ERROR CODE IDENTIFICATION

16.1

The below information identifies the manifold component with its associated error code. Refer to error codes listed on page 8.



17. ELECTRICAL TESTING

17.1

A digital multimeter is a useful tool for troubleshooting and isolating electrical related problems. Open circuits are identified by no continuity shown on the display (1OL). Open circuits in the SLS manifold electrical system are typically caused by pins that have pulled loose from the associated harness connector, wires that are broken at the pins in the harness connector, breaks in the coil windings, or broken wires in the wiring harness due to improper harness routing during the installation of the system.

17.2

The coil can be tested for an "open" or "short" circuit by checking the resistance value of the windings. The coil must first be isolated by disconnecting its associated wiring harness connector. Obtain a multimeter as previously suggested and rotate the dial to the OHMS (resistance) setting. In most cases, this should turn on the power to the multimeter. If not, turn on the required switch to power the multimeter. Connect the red lead of the multimeter to the power lead in the wiring harness connector of the coil to be tested.

Figure 4

17.3

Next, connect the black lead of the multimeter to the black lead in the wiring harness connector of the coil to be tested. The display on the multimeter should read approximately 8 to 10 ohms of resistance. If the display of the multimeter shows zero ohms of resistance, the coil is "shorted" and requires replacement. If the display shows an "open" circuit, as indicated by displaying "1OL", the coil requires replacement, as well.

17.4

NOTE

Prior to disconnecting the manifold wiring harness to perform the continuity check, be sure power has been removed from the SLS system ECU. This can be accomplished by turning the ignition switch to the "OFF" position. This prevents the SLS system from operating when the engine is not running, which could result in unanticipated suspension movement.

17.5

The SLS system requires 12 VDC for proper system operation. The ECU uses the 12 VDC supplied by a user defined vehicle power source to control the manifold valve coils and also uses the voltage to create an internal 5 VDC reference signal. This lower voltage provides feedback to the ECU from the system sensors to detect and maintain the vehicle ride height. Therefore, if the supply voltage is either excessively low (typically less than 9.7 VDC) or excessively high (typically 14.8 VDC or above) system performance can be adversely affected.

17.6

The multimeter, using the DC voltage scale, is also a useful tool in checking and verifying the correct supply voltage and that a good system and manifold ground is present. The system ground and manifold ground are provided through separate ground wires. Refer to the SLS wiring diagrams to determine the power and ground wires associated with the system.

17.7

NOTE

DC voltage is polarity sensitive. Therefore the multimeter red lead should be connected to positive (system power: 12 VDC) and the black lead connected to negative (system ground).— The Spartan system schematic layouts are illustrated later in this manual on pages 20 and 21.

17.8

COMMENT

Open and short circuits in the wiring harness are often the direct result of improper installation procedures. Link engineering has created separate documentation to serve as a guide for installation of the electrical and pneumatic hardware. However, there is no guarantee these installation procedures and associated document recommendations are adhered to by installation personnel. It is often the service personnel who must address and correct issues that arise from installation errors.—The Spartan system pneumatic layout is illustrated later in this manual on page 22.

17.9 COMMENT

Leaks associated with the tubing and pneumatic components are often the direct result of improper installation procedures. Link engineering has created separate documentation to serve as a guide for installation of the pneumatic hardware. However, there is no guarantee these installation procedures and associated document recommendations are adhered to by installation personnel. It is often the service personnel who must address and correct issues that arise from installation errors.

18. REMOTE FILL PANEL

18.1

Some systems are equipped with a Remote Fill Panel which will be located on the left front of the vehicle (unless otherwise specified). This can be used to check the pressure of the Air Springs or can be used to manually adjust the system in Emergency Situations.



Figure 5

18.2 NOTE

Please be sure to remove power from the leveling system prior to manual adjustment. This can be done by removal of its fusing or by switching off the appropriate circuit breaker associated with the system. Do not over inflate the air springs, MAX PRESSURE IS 100PSI.

19. SUMMARY

19.1

This completes the operation and service information regarding the SLS manifold and valve assemblies. The information contained in this document is not intended to be all inclusive but to serve as a reference document. Time spent by installation and service personnel to better acquaint themselves with this information will provide a greater understanding of system operation and the associated servicing procedures.

20. SLS INCLINATION SENSOR

20.1

This section is written to provide a basic understanding of the inclination sensors used on the Self Leveling System (SLS). This discussion will create a basic understanding of the sensor functionality. The knowledge gained by understanding this information will provide installation and service personnel with information to diagnose and repair related system problems.





21. THEORY OF OPERATION

21.1

The sensor is used by the system ECU (electronic control unit) to detect the angle change of the vehicle chassis from the true horizontal position, using reliable hall-effect technology. It enables the ECU to monitor the vehicle chassis angle and determine if adjustment to the horizontal position of either axis is necessary during the self-leveling mode of operation.

21.2

The two sensors are mounted on or near the SLS manifold assembly. One sensor monitors the "X" axis (side to side) and the second sensor monitors the "Y" axis (front to back) of the vehicle chassis. The sensor contains three wires (red, black, white) that interface with the system ECU through a supplied vehicle wiring harness. The red wire provides an ECU generated reference voltage, typically 5 VDC (+/- 2%). The black wire provides the ground and the white wire provides the voltage signal back to the ECU. This voltage is proportional to the angle of the sensor from the horizontal position.

21.3

With the chassis of the vehicle level, the voltage signal on the white wire is one-half of the supplied reference voltage (approximately 2.5 VDC to 2.7 VDC). As the front of the sensor is raised, the voltage on the white wire will increase until the sensor reaches approximately a 10 degree angle from the horizontal position. With the front of the sensor raised to this angle, the voltage on the sensor's white wire will be approximately 4.5 VDC. The sensor angle change in this direction would be typical in an uphill slope of the chassis.

21.4

As the rear of the sensor is raised, the voltage on the white wire will decrease until the sensor reaches approximately a 10 degree angle from the horizontal position. With the rear of the sensor raised to this angle, the voltage on the sensor's white wire will be approximately 0.5 VDC. The sensor angle change in this direction would be typical in a downhill slope of the chassis.

21.5

It is important to clarify the sensor only monitors the angle of change and provides feedback to the ECU through 20 degrees of movement. In other words, from the center position, an angle increase of 10 degrees or decrease of 10 degrees will provide a change in the feedback signal to the ECU. Movement beyond this range will provide no additional change in the feedback signal. Therefore, it is important to mount the sensors as level as possible in both the "X" and "Y" directions to optimize the sensor feedback capability.



22. SENSOR MOUNTING

22.1

The sensors require mounting to the required surface by using two 8/32NF X $\frac{1}{2}$ " Long socket head cap screws (SHCS) and flat washers nylock nuts and tightened to 20 in/lbs. of torque. The top surface of the sensor should be checked and verified to be level in the "X" and "Y" direction after securing the sensors to the mounting surface.

22.2

After the manifold is properly mounted and secured in the designated vehicle location, connect the sensor wiring harness connectors. The "X" axis connector will typically be of a female configuration, while the "Y" axis connector will typically be of a male configuration. This interface is an assembly poka-yoke, making it impossible to connect the sensor to the wrong harness connector. Additional poka-yoke measures have been taken to color code the center wire of the vehicle wiring harness connector, as well. The typical vehicle wiring harness center wire color code configuration is as follows:

Wiring Harness Blue Wire = "X" axis inclination sensor Wiring Harness Violet Wire = "Y" axis inclination sensor

22.3 NOTE

Prior to connecting the wiring harness to the sensor connectors, be sure to apply a good brand of moisture displacement lubricant to the connectors. This will help prevent moisture from entering the connections and affecting system operation due to the low current and voltage application of the sensor.

23. SENSOR TEST PROCEDURE

23.1

The ECU monitors the system and can identify voltages that are below 0.4VDC (short to ground, broken wire, disconnected harness connector, etc.) or voltages equal to the supply reference (short to supply voltage). Voltages associated with these conditions would generate an alarm. The alarm would be displayed by a fault code on the vehicle user panel by flashing the suspension indicator. However, voltages that are above 0.4VDC and below the supply reference from the ECU falls within the normal operating parameters of the sensor and are not subject to alarm. If a sensor is suspected to be faulty, a test can be performed to validate its functionality.

23.2

The following step by step process outlines that test procedure:

 Remove power from the system prior to performing any repairs or component removal/replacement. This will prevent any possible short circuits that could result in component or supply voltage damage. This is accomplished by turning the ignition switch to the "OFF" position.

- 2. Disconnect the respective sensor 3-wire connector from the vehicle wiring harness.
- 3. Remove the two mounting screws with washers that secure the sensor to the mounting surface.
- Remove the sensor from the vehicle. Place the sensor on a clean and level surface. Verify the surface to be used is level by using an appropriate level across the "X" and "Y" planes of the surface.
- 5. Orientate the sensor in such a manner as to have the wires on your left hand side and facing towards you (refer to the previous illustration on page 21).
- 6. Obtain a DC voltage power supply capable of
- 7. supplying a regulated 5 VDC supply.
- Do not exceed 5 vdc while testing the sensor!
- 7. Connect the red lead from the power supply to the red wire on the sensor connector.
- 8. Connect the black lead from the power supply to the black wire on the sensor connector.
- 9. Obtain a voltmeter to monitor the feedback voltage.
- 10. Connect the red lead of the voltmeter to the sensor white wire and the black lead of the voltmeter to the sensor black wire.
- 11. Turn on the DC power supply and adjust the voltage to 5 VDC, if necessary.
- 12. With the sensor sitting flat on the horizontal surface for testing, the voltage on the white wire should read approximately one-half of the 5VDC supply, i.e. 2.5 VDC to 2.7 VDC.
- 13. Slowly raise the front of the sensor (sensor end on your left hand side, with the wires), while keeping the rear of the sensor (the sensor end on your right hand side) in contact with the horizontal flat surface. The voltage on the voltmeter should steadily increase until an approximate angle of 10 degrees is reached. With the front of the sensor at this angle, the voltage on the voltmeter should read approximately 4.5 VDC. Any further increase in the angle beyond this point will not result in any further increase in the feedback voltage.

NOTE

The voltage should increase steadily, with no loss in the voltage signal, no erratic changes should occur, or the voltage should not read +5 VDC or 0 VDC at any point throughout the angle of movement.

- 14. Return the sensor to the full horizontal position.
- 15. Slowly raise the rear of the sensor (sensor end on your right hand side), while keeping the front of the sensor (the sensor end on your left hand side, with the wires) in contact with the horizontal flat surface. The voltage on the voltmeter should steadily decrease until an approximate angle of 10 degrees is reached. With the rear of the sensor at this angle, the voltage on the voltmeter should read approximately 0.5 VDC. Any further increase in the angle beyond this point will not result in any further decrease in the feedback voltage

NOTE

The voltage should decrease steadily, with no loss in the voltage signal, no erratic changes should occur, or the voltage should not read 0VDC or +5VDC at any point throughout the angle of movement. 16. If the sensor fails to test as described, then replacement will be necessary.

23.3 NOTE

When replacing the sensor (or upon re-installation in the event of a satisfactory test), be sure to adhere to the installation instructions mentioned earlier in this document. It is imperative for the sensor to be level and be properly secured to the mounting surface. This will ensure accurate monitoring by the system ECU and provide proper system functionality during the self-leveling mode of operation.

24. SUMMARY

24.1

This completes the basic installation, operation, and troubleshooting information on the inclination sensor. Time spent by installation and service personnel to better understand individual component functions will enhance their understanding of overall system operation. It will also ensure a properly installed and serviced system, thereby optimizing system performance and obtain the intended system functionality.

25. SLS PRESSURE TRANSDUCER

25.1

This section is written to provide a basic understanding of the pressure transducer used on the Self Leveling System (SLS). This discussion will create a basic understanding of the transducer functionality. The knowledge gained by understanding this information will provide installation and service personnel with information to diagnose and repair related system problems.



26. THEORY OF OPERATION

26.1

This device is used by the system ECU (electronic control unit) to monitor a specific pneumatic pressure within the Self Leveling System. This system consists of a single pressure transducer for monitoring the vehicle main air supply to achieve the desired system functionality. The transducer is of a highly reliable ceramic design, utilizing a variable capacitance sensing element, and state-of-the-art integrated circuitry to provide a linear voltage signal proportional to the applied system pressure.

26.2

The pressure transducer is installed into an appropriate air fitting at a suitable location within the pneumatic system. This enables the capacitive sensing element of the transducer to be directly subjected to the system air pressure at the desired point. The integrated circuitry converts the sensed system air pressure into a useable electrical signal. This electrical signal is detected by the system ECU and is used to determine if sufficient system pressure is available to provide for proper SLS operation. This pressure must be within the range of 95 – 130 psi. If the pressure is below this range, the ECU will illuminate the air pressure indicator located on the user interface, to serve as a warning to the vehicle operator of a system air pressure problem.

26.3

The system wiring harness connector contains three wires (typically orange, black, blue) that interface the system ECU to the sensor. The orange wire provides an ECU generated reference voltage, typically 5 VDC (+/- 2%). The black wire provides the ground and the blue wire provides the voltage signal back to the ECU. This voltage is proportional to the respective system air pressure detected by the transducer.

26.4

With power applied to the ECU and no pressure applied to the transducer the voltage on the transducer connector blue wire will be approximately 0.5 VDC. As the pressure on the transducer increases, the voltage will increase at a linear rate.

The following chart exemplifies a transducer with a typical 0 - 150 psi sensing range:

Pressure Transducer Comparison Chart Applied Pressure vs Output Voltage

Applied Pressure (psi)	Voltage Output (VDC)
0	0.5
10	0.7
20	0.9
30	1.25
40	1.5
50	1.75
60	2.0
70	2.25
80	2.5
90	2.75
100	3.1
110	3.4
120	3.75
130	3.9
140	4.25
150	4.5

Figure 9

27. TRANSDUCER MOUNTING

27.1

The pressure transducer contains 1/8"-27 NPT threads and is installed at a suitable location within the system. The threads of the transducer contain a factory installed sealant to prevent air leaks. The ceramic housing is durable and the brass body resists corrosion and helps prevent the threads from seizing within the fitting, thereby assisting with future serviceability.

27.2

After the transducer is properly mounted and secured in the designated vehicle location, attach the associated wiring harness connector to the sensor body. The system wiring harness connector is of a male configuration. The center wire of the wiring harness is color coded for a specific transducer. The following provides the wire color associated with the single transducer function:

Wiring Harness Blue Wire = System Pressure Transducer

27.3 NOTE

Prior to connecting the system wiring harness connector to the transducer, be sure to apply a good brand of moisture displacement lubricant to the connector. This will help prevent moisture from entering the connection and affecting system operation due to the low current and voltage application of the transducer.

28. TRANSDUCER TEST PROCEDURE

28.1

The ECU monitors the system and can identify voltages that are below 0.4 VDC (short to ground, broken wire, disconnected harness connector, etc.) or voltages equal to the supply reference (short to supply voltage). Voltages associated with these conditions would generate an alarm. The alarm would be displayed by a fault code on the vehicle user control panel by flashing the suspension indicator. However, voltages that are above 0.4 VDC and below the supply reference from the ECU fall within the normal operating parameters of the transducer and are not subject to alarm. If a transducer is suspected to be faulty, a test can be performed to validate its functionality.

28.2

The following step by step process outlines that test procedure:

- Remove power from the system prior to performing any repairs or component removal/replacement. This will prevent any possible short circuits that could result in component or supply voltage damage. This can be accomplished by turning the ignition switch to the "OFF" position. Relieve pressure from the system through an appropriate means.
- 2. Relieve pressure from the system through an appropriate means.

AWARNING

System operating pressures are typically 95-130 psi. To avoid the potential of personal injury, do not remove the transducer without first relieving pressure from the system.

- 3. Disconnect the wiring harness 3-wire connector from the pressure transducer.
- Unscrew the transducer from the associated fitting. NOTE: Use a back-up wrench if necessary to relieve stress on the associated fitting while loosening the transducer.
- 5. Obtain a known good air pressure regulator, with an accurate gauge.
- Obtain a DC voltage power supply capable of supplying a regulated 5 VDC supply. Do not exceed 5 vdc while testing the Transducer!
- 7. Attach a shop air supply line to the inlet of the pressure regulator. Be sure the regulator adjustment has been backed off completely to prevent any air discharge from the regulator outlet.
- 8. Secure the transducer to the regulator output, utilizing an appropriate reducer fitting. Be sure to use a suitable thread sealant to prevent an air leak, if necessary. Also do not use an excessive amount of sealant that could possibly clog the air inlet to the pressure transducer.
- 9. Assemble and install an electrical test connector onto the pressure transducer, using the same wire colors and pin configurations as the original wiring harness connector.
- 10. Connect the red lead from the power supply to the orange wire on the transducer test connector.

- Connect the black lead from the power supply to the black wire on the transducer test connector. Obtain a voltmeter to monitor the feedback voltage.
- 12. Connect the red lead of the voltmeter to the transducer test connector blue wire (signal) and the black lead of the voltmeter to the transducer test connector black wire.
- 13. Turn on the DC power supply and adjust the voltage to 5VDC, if necessary.
- 14. With no pressure applied to the transducer, the voltmeter should read approximately 0.5VDC.
- 15. Refer to the chart illustrated on page 16 of this document.
- 16. Slowly increase the pressure on the regulator outlet in 10 psi increments. Record the voltmeter readings at 10 psi, 20 psi, 30 psi, 40 psi, 50 psi, 60 psi, 70 psi, 80 psi, 90 psi, 100 psi, 110 psi, 120 psi, and if possible, 130 psi, 140 psi, and 150 psi. The voltmeter should read +/- 2% of the voltage listed in the chart at these respective pressures.

NOTE

The voltage should increase steadily, with no loss in the voltage signal, no erratic changes should occur, or the voltage should not read 0 VDC or +5 VDC at any point throughout the test range.

17. If the sensor fails to test as described, then replacement will be necessary.

28.3

When replacing the transducer (or upon re-installation in the event of a satisfactory test), be sure to adhere to the installation instructions mentioned earlier in this document. It is important for the transducer threads to be properly sealed with an appropriate sealant in order to be free of air leaks. This will ensure proper monitoring by the system ECU and prevent excessive air compressor cycling from the loss of system pressure.

29. SUMMARY

29.1

This completes the basic installation, operation, and troubleshooting information on the pressure transducer. Time spent by installation and service personnel to better understand individual component functions will enhance their understanding of overall system operation. It will also ensure a properly installed and serviced system, thereby optimizing system performance and obtain the intended system functionality.

30.SLS HEIGHT SENSOR

30.1

This section is written to provide a basic understanding of the SLS Height Sensor. The content is not intended to be all inclusive, but is to provide basic knowledge for mounting the sensor, the sensor function, and to provide a basic troubleshooting procedure.



Figure 10

31. THEORY OF OPERATION

31.1

The height sensor is used by the system ECU (electronic control unit) to monitor and control the vehicle ride height. The sensor arm moves in reaction to the suspension movement and provides a voltage signal that is proportional to the ride height at any given time. Typically, while the vehicle is in operation, the ECU will default to and maintain a programmed ride height. This system design requires a four sensor configuration: two front sensors and two rear sensors, one mounted at each corner of the vehicle suspension. This 4-point configuration enables each corner of the vehicle to be controlled independently of the other three.

31.2

The sensor contains three wires (red, black, blue) that interface with the system ECU through the supplied system wiring harnesses. The red wire provides an ECU generated reference voltage, typically 5 VDC (+/-2%). The black wire provides the ground and the blue wire provides the voltage signal back to the ECU. This voltage is proportional to the position of the sensor arm within its range of travel.

31.3

The sensor arm is typically installed to be in the center of its travel, when the vehicle is at normal ride height. This would provide a voltage signal on the blue wire that is one-half of the supplied reference voltage (approximately 2.4 VDC – 2.6 VDC). As the sensor arm moves clockwise, the voltage on the blue wire would continue to increase until the sensor arm reaches approximately +45 degrees of rotation from the center position. At the +45 degrees of rotation, the voltage on the sensor's blue wire would be approximately 4.4 VDC to 4.6 VDC. The sensor arm travel in the clockwise direction would be typical in a decrease situation from the normal vehicle ride height.

31.4

As the sensor arm moves counter-clockwise, the voltage on the blue wire would continue to decrease until the sensor arm reaches approximately -45 degrees of rotation from the center position. At the -45 degrees of rotation, the voltage on the sensor's blue wire would be approximately 0.4 VDC to 0.6 VDC.

31.5

The sensor arm travel in the counter-clockwise direction would be typical in an increase situation from the normal vehicle ride height.

31.6

It is important to clarify that the sensor only monitors the ride height and provides feedback to the ECU through only 90 degrees of movement. In other words, from the center position, a change in the ride height of +45 degrees to -45 degrees of sensor arm movement provides a signal to the ECU. Movement either above or below this range provides no additional feedback to the ECU. Therefore it is important to install the sensor correctly to obtain the correct linkage arm inclination (see SLS Height Sensor Arm & Linkage Installation procedure outlined in Appendix C). Improper linkage installation can result in sensor damage and result in improper system control and incorrect vehicle ride height.



32. SENSOR MOUNTING

32.1

Care must be taken when mounting the sensor to the vehicle frame. The mounting surface must be flat so the sensor body is mounted flush to the vehicle surface. It is recommended that two hex head cap screws, $\frac{1}{4}$ " – 20 thread, be used to mount the sensor to the vehicle and the screws tightened to 60-80 inch/lbs. of torque. If the frame mounting holes are a through-hole (non-threaded), a nylon style of locknut is also recommended to maintain the tightening torque.

32.2

It is important to clarify the above mounting information, otherwise distortion or breakage of the sensor body is possible when tightening the mounting hardware. Not having the sensor flush can distort the sensor body resulting in breakage as well as over-tightening can crack the housing. Damage to the senor will result in improper system control and incorrect vehicle ride height.

32.3

After the sensor is mounted to the vehicle, connect the sensor wiring female connector to the respective vehicle wiring harness male connector. The center wire of the vehicle wiring harness connector will be color coded to identify the respective location on the vehicle. The supplied system wiring harness center wire configuration is as follows:

Yellow Wire = Front Driver Side Height					
Sensor Connector					
Green Wire = Front Curb Side Height					
Sensor Connector					
Yellow Wire with Black Stripe = Rear Driver Side					
H	leight Sensor				
C	Connector				
Green Wire with Black Stripe = Re	ear Curb Side Height				
S	ensor Connector				
Green Wire with Black Stripe = Ro	ear Curb Side Height				

32.4 NOTE

Prior to connecting the wiring harness to the sensor connectors, be sure to apply a good brand of moisture displacement lubricant to the connectors. This will help prevent moisture from entering the connections and affecting system operation due to the low current and voltage application of the sensor.

33. SENSOR TEST PROCEDURE

33.1

The ECU monitors the system and can identify voltages that are below 0.4 VDC (short to ground, broken wire, disconnected harness connector, etc.) or voltages equal to the supply reference (short to supply voltage). Voltages associated with these conditions would generate a sensor alarm. The alarm would be displayed by flashing a fault code on the user control panel suspension indicator. However, voltages that are above 0.4 VDC and below the supply reference from the ECU fall within the normal operating parameters of the sensor and are not subject to alarm. If a sensor is identified to be faulty, a test can be performed to validate its functionality.

33.2

The following step by step process outlines that test procedure:

- Remove power from the system prior to performing any repairs or component removal/replacement. This will prevent any possible short circuits that could result in component or supply voltage damage. This can be accomplished by turning the ignition switch to the "OFF" position.
- 2. Disconnect the sensor 3-wire connector from the supplied system wiring harness.
- 3. Disconnect the linkage from the sensor arm.
- 4. Unbolt the sensor from the vehicle frame and remove the sensor.
- Obtain a DC voltage power supply capable of supplying a regulated 5 VDC supply. Do not exceed 5 vdc while testing the angle sensor!
- 6. Connect the red lead from the power supply to the red wire on the sensor connector.
- 7. Connect the black lead from the power supply to the black wire on the sensor connector.
- 8. Obtain a voltmeter to monitor the DC feedback voltage.
- 9. Connect the red lead of the voltmeter to the sensor blue wire and the black lead of the voltmeter to the sensor black wire.
- 10. Orientate the sensor so the back of the device is flush with a hard surface, the lever arm faces up and points to your left, and the sensor wiring is to your right.
- 11. Place the sensor in the mid-range of its travel.
- 12. Turn on the DC power supply and adjust the voltage to 5 VDC, if necessary.
- With the sensor arm in the center position, the voltage on the blue wire should read approximately one-half of the 5 VDC supply, i.e. 2.4 VDC to 2.6 VDC.

14. Slowly rotate the senor arm in the clockwise direction and observe the voltage reading on the voltmeter. As the sensor arm is rotated clockwise, the voltage on the blue wire should increase until approximately +45 degrees of rotation from center is reached. At the +45 degrees of rotation, the voltage should read approximately 4.4 VDC to 4.6 VDC. If rotation continues beyond this point, no additional increase in voltage should be observed.

NOTE

The voltage should increase steadily, with no loss in the voltage signal, no erratic changes should occur, or the voltage should not read +5VDC or 0VDC at any point throughout the range of movement.

15. After verifying the voltage increase, slowly rotate the sensor arm counter-clockwise. As the sensor arm is rotated counter-clockwise, the voltage on the blue wire should decrease until approximately -45 degrees of rotation from center is reached. At the -45 degrees of rotation, the voltage should read approximately 0.4 VDC to 0.6 VDC. If rotation continues beyond this point, no additional decrease in voltage should be observed.

NOTE

The voltage should decrease steadily, with no loss in the voltage signal, no erratic changes should occur, or the voltage should not read 0 VDC or +5 VDC at any point throughout the range of movement.

16. If the sensor fails to test as described, then replacement is necessary.

33.3 NOTE

When replacing the sensor (or upon re-installation in the event of a satisfactory test), be sure to adhere to the installation instructions mentioned earlier in this document. Proper installation is necessary to prevent damaging the sensor. Proper sensor operation is necessary to provide accurate feedback to the ECU for correct vehicle ride height control.

34. SUMMARY

34.1

This completes the basic installation, operation, and troubleshooting information on the height control sensor. All information contained in this document is of equal importance and should not be ignored. Time spent by installation and service personnel to better understand component operation will ensure a properly installed and serviced system, thereby providing correct system operation.

35. SLS FRONT HARNESS LAYOUT





35. SLS FRONT HARNESS LAYOUT



36. SLS PNEUMATIC LAYOUT 37. APPENDIX A

37.1

SLS Wiring Harness Installation Precautions

 Be sure the utilized vehicle power source is not overloaded or undersized. Sufficient system power is required to optimize the manifold solenoid-valve operation, i.e.10 VDC- 16 VDC, 1.2 Amp per solenoid.

NOTE

When testing the system, in order to provide correct system operation, a constant DC power source, such as a battery must be utilized. A source consisting of a pulsating DC, such as a battery charger, is not adequate to provide the power necessary for ensuring system operation and proper functionality.

- 2. Be sure the power and ground connections are clean and tight and the manifold ground wire(s) are connected to a good chassis ground.
- 3. Be sure the harness is routed correctly so as the height sensor connectors are installed to the correct sensor on the vehicle. The following describes the center wire color of the system harness connectors and their associated sensor connection:
 - Yellow Wire = Front Driver Side Height Sensor Connector Green Wire = Front Curb Side Height Sensor Connector Yellow Wire with Black Stripe = Rear Driver Side Height Sensor Connector Green Wire with Black Stripe = Rear Curb Side Height Sensor Connector
- 4. DO NOT pull on the harness connectors excessively during the installation process. Too much force on these components can pull wires from the connector or break wires from their pin crimp connection.
- Keep the harness away from engine exhaust manifolds, mufflers, exhaust pipes, catalytic converters, and other heat generating components.
- 6. Keep the harness away from pinch points and sharp objects to prevent crushing, cutting, and damage to the harness assembly which could

result in open or short circuits.

- 7. Allow sufficient bend radii where applicable to prevent sharp bends, kinks, and unnecessary strain on the wiring that could result in eventual breakage and open circuits. The conduit manufacturer recommends a minimum bend radius of 3-inches.
- 8. Allow sufficient slack in the harness to prevent damage at points of vehicle horizontal and/or vertical movement and deflection. This will allow the harness to move with the vehicle and prevent unnecessary stress and fatigue resulting in eventual open and/or short circuits

NOTE

Caution should be taken as not to leave excessive slack which could cause the harness to become snagged while the vehicle is in motion, especially in off road conditions.

- 9. Secure the harness every few inches (typically 6 -12") with nylon straps.
- 10. While securing the harness with the nylon straps, care should be taken as not to crush the polyethylene flexible split conduit.
- 11. Be sure the rubber moisture seal is in place on the connectors. This will help to prevent moisture from entering the connection and affecting system operation.
- 12. Be sure to apply a good brand of moisture displacement lubricant to the connectors prior to connecting them to their associated sensor/field device. (A good product for this application is Super Lube Silicone Dielectric Grease available through MSC Industrial Supply, P/N 02105658). This will help to prevent moisture from entering the connection and affecting system operation.
- 13. When connecting the harness to the vehicle field devices, i.e. sensors, switches, etc. be sure the connector is properly orientated by the connector's keying mechanism and that the connectors are fully inserted so the latching mechanism is fully engaged. This will help to ensure a positive electrical connection, allowing for correct ECU monitoring and control.
- 14. Be sure to seal any holes which may have been created for routing and installation of the ECU harness connectors, if required with an off the shelf expanding foam. A good product for this application is Federal Process Corporation Work Saver Expanding Foam available through MSC

Industrial Supply, P/N 36913622. 38. APPENDIX B

38.1

SLS Pneumatic Installation Precautions

- Be sure the air supply provides sufficient pressure to allow for proper system operation, typically 95 – 130 psi. Pressures excessively above or below this range can affect system performance and can result in incorrect vehicle ride height.
- If an existing air reservoir is to be used for providing the source air supply, be sure to tap into the source at some point above the bottom of the tank. Moisture settles to the bottom of the tank and the ports in this location are best suited for drain valves.
- 3. Be sure the source air supply is as clean and dry as possible. The air supply should be equipped with an industry standard filtration system.
- Mount the SLS system manifold assembly higher than the lowest point in the air system to reduce the possibility of catching air system contamination.
- Mount the SLS air tank (if applicable) so as not to interfere with the suspension or frame movement. The tank should be orientated as such in order to place the drain valve(s) facing toward the ground, beneath the vehicle.
- Be sure to use either Teflon tape or a heavy duty thread sealing compound on any field installed air fittings prior to installation, (if the fittings are not already provided with sealant on the threads). Either sealant type can be purchased from any local hardware store.

NOTE

If the use of Teflon tape or a heavy duty thread sealing compound is required, care should be taken with its application so as not to obstruct the air passage in the fitting or clog the manifold port screens.

- 7. The tubing should be installed to adhere to the following routing and connections:
 - a. Manifold Supply Inlet Port = Supply Line from Vehicle Source
 - b. Manifold Port A = Front Driver Air Spring
 - c. Manifold Port B = Front Curb Air Spring
 - d. Manifold Port C = Rear Drive Air Springs
 - e. Manifold Port D = Rear Curb Air Springs
 - f. Manifold Exhaust Port = Route and secure tubing to vehicle undercarriage
- 8. Route the tubing away from engine exhaust manifolds, mufflers, exhaust pipes, catalytic converters, and other heat generating components.
- 9. Keep the tubing away from pinch points and sharp and jagged edges to prevent crushing, pinching, or puncturing of the tubing. Tubing that is damaged in this way can reduce air flow and results in poor

system performance.

10. Air brake tubing is recommended for system installation, Parker Hannifin, P/N PFT-6B. Allow sufficient bend radii, where applicable, to prevent sharp bends and kinks in the tubing. The tubing manufacturer recommends a minimum bend radius of 1-1/2" for tubing with an outside diameter (O.D.) of 3/8" (0.375").

NOTE

If a kink should occur during the installation process, the tubing must be carefully inspected in the area of the kink for possible permanent damage and/or obstruction. The kink can weaken the tensile strength of the tubing and create a weak spot where a leak could develop. Also the tubing must be free of obstructions which can reduce the amount of airflow and affect system performance.

11. Allow sufficient slack in the tubing to prevent damage at points of vehicle horizontal and/or vertical movement and deflection. This will allow the tubing to move with the vehicle and prevent crushing and/or fatiguing of the tubing.

NOTE

Caution should be taken as not to leave excessive slack which could cause the tubing to become snagged while the vehicle is in motion, especially in off road conditions.

- 12. Secure the tubing every few inches (typically 6 -12") with nylon straps.
- 13. The nylon straps should be snug enough to hold the tubing in the desired position, but not overtightened, which can otherwise distort the tubing and restrict air flow.
- 14. To prevent leaks, be sure the tubing end is cut square and the tubing is free from nicks, cuts, abrasions, and any contaminates (such as rust-proofing) at least 3 4 inches from the squarely trimmed end, prior to attaching the tubing to the fittings.

NOTE 1

A tubing cutter with a sharp blade is recommended to properly cut the tubing end. (A good tubing cutter can be purchased from either MSC Industrial Supply, P/N 79814323, or from Parker Hannifin Corporation, P/N PTC). It is not recommended to use any other device for cutting the tubing. If an improper tool is used, uneven cuts, jagged edges, or distortion of the tubing can result, thereby affecting the ability for the tubing to fully engage the fitting. The tubing must fully engage the fitting and be free from damage for air leak prevention.

NOTE 2

If circumstances arise which requires disconnecting the tubing from a PTC fitting, careful examination of the tubing end is required. It is possible for the tubing end to become distorted and irregularities may be present in the tubing wall. If any distortion or irregularities are present, it will be necessary to trim off the damaged end (typically 1/2" is sufficient) by using a good tubing cutter. Removal of the damaged end and using the appropriate tool will ensure a positive seal between the tubing wall and the inside diameter of the PTC fitting. Be sure to check the area with a good leak detection solution after pressurizing the system to ensure that no leak is present. If a bubbling of the inspection solution is present, it may be necessary to replace the PTC fitting, as well.

- 15. Install the tubing into the fitting (compression fittings): (A) Slide the fitting nut over the end of the tubing (threaded end facing the fitting), making sure the insert is in place inside the fitting;
 (B) Insert the tubing inside the fitting and push down as far as possible. (C) Secure the nut to provide a positive seal between the insert, the tubing, and the nut.
- 16. Install the tubing into the fitting (manifold fittings): Simply push the hose completely into the fitting until it locks. This style of fitting is of a push-toconnect (PTC) design. When properly installed, the tubing will not pull from the fitting unless the

release mechanism is depressed.

17. After completing the installation and verifying system operation, the entire air system should be inspected for leaks utilizing a suitable leak detection solution. This may include a soap, water, and glycerin mix, Oatey All-Purpose Leak Detector, or Nu-Calgon Gas Leak Detector (the Oatey and Nu-Calgon products are available through MSC Industrial Supply).

38.2 NOTE

It is important to pay particular attention to the vehicle air springs. Leaks in these areas will affect the SLS system operation and performance and often go undetected, unless the leak is severe enough to cause the vehicle to lean, when the vehicle has been idle (such as overnight parking). During the inspection of the air springs, pay particular attention to the interface of the upper bead plate to the air spring/bag lip area. Should a leak be detected in the air spring, it must be replaced as defined by the vehicle manufacturer's warranty/replacement procedure.

38.3

Detecting air leaks and taking corrective action will optimize system performance, eliminate unnecessary troubleshooting, prevent system rework, and prevent unnecessary air compressor wear due to excessive

cycling. 39. APPENDIX C

39.1

SAMS Height Sensor Arm & Linkage Installation

- With the vehicle on a level surface, determine the amount of jounce (compression) travel and the rebound (extending) travel of the suspension. These two dimensions indicate the range of movement for which the suspension can respond to changes in road conditions.
 Example: jounce travel = 3" rebound travel = 4"
- Determine which range of travel is the largest distance and make note. The example provided in step #1 would have the "rebound travel" of 4" to be the greater of the two distances.
- 3. Using the table below, select the lever length needed based on the largest distance noted in the above example. The prior example defined the largest direction of movement to be 4" (rebound). In the left most column, find 4" of suspension travel. Go across the rows and in the right most column, select the "recommended minimum lever length" needed. The example provided would require a 6" height sensor arm with the 4" of

Height Sensor Arm Selection Table

Jounce or Rebound Maximum Suspension Travel at Lower Linkage Connection	Recommended Minimum Lever Length	
2.0"	3.0"	
2.2"	4.0"	
2.4"	4.0"	
2.6"	4.0"	
2.8"	5.0"	
3.0"	5.0"	
3.2"	5.0"	
3.4"	5.0"	
3.6"	6.0"	
3.8"	6.0"	
4.0"	6.0"	
4.2"	7.0"	
4.4"	7.0"	
4.6"	7.0"	
4.8"	8.0"	
5.0"	8.0"	
5.2"	8.0"	
5.4"	9.0"	
5.6"	9.0"	
5.8"	9.0"	
6.0"	9.0"	

maximum suspension travel.

- 4. Attach the height sensor to the vehicle frame by adhering to precautions outlined in the height sensor section of the manual. This section provides useful information to prevent possible damage to the height sensor during the installation and servicing process, as well as troubleshooting procedures.
- 5. Under most circumstances, with the vehicle at the recommended ride height, the sensor arm should be located in the center of its travel. The sensor arm position at center should be such that it corresponds to the approximate center of the controlled air spring(s) travel. Ideally, the sensor when properly located will provide a range of movement between 30 and 42 degrees from either side of center. This range of movement is necessary for creating sufficient voltage signal variations to the ECU, thereby enabling accurate ride height control.

NOTE

In applications with two sensors on the same axle, be sure the linkages are adjusted equally. Also, it is important to clarify that the "standard" (normal) ride height is to be adjusted to the original manufacturer specifications. Refer to the Original Equipment Manufacturer (OEM) service manual for further information regarding the adjustment procedure and the ride height specifications.

6. Attach the associated linkage to the sensor arm and the vehicle suspension or axle. It is important to note the point where the linkage attaches to the height sensor arm should lead the connection point at the vehicle suspension/axle a distance that is approximately 20% of the sensor arm length. See the illustration below for more details on the proper lever arm inclination dimension (LAI) for the



linkage, based on the required sensor arm. **NOTE**

The inclination of the linkage is important to ensure the continuous monitoring of the suspension throughout its travel (jounce and rebound). The sensor monitoring range is typically +/- 45 degrees from the center position (90 degrees of rotation total). Points outside of this range will not provide any further changes in the feedback signal to the system ECU. Also, if the sensor arm is too short and the inclination angle is incorrect, it is possible to over-extend the height sensor. This would result in damage to the sensor and cause faulty system operation.

- Route the SAMS wiring harness as required, adhering to the precautions outlined in the associated installation documentation. The document provides useful information to prevent possible damage to the wiring harness and/or connectors during the installation process and vehicle operation.
- 8. Connect the respective wiring harness 3-pin connectors to each height control sensor. Refer to the wiring harness installation precaution documentation for connector identification and moisture prevention procedures.
- 9. Route and install the air tubing, adhering to the precautions outlined in the pneumatic installation documentation. The document provides useful information to prevent damage to the nylon tubing and precautions to help in the prevention of air

leaks.

10. After the installation of the sensors, wiring harness, ECU, operator control panel, and the pneumatic components, the system is ready for power up and test. Start the vehicle to supply power and air to the SAMS system. The system should go through a self-leveling test and automatically adjust to a predefined point.

NOTE

When testing the system, in order to provide correct system operation, a constant DC power source, such as a battery must be utilized. A source consisting of a pulsating DC, such as a battery charger, is not adequate to provide the power necessary for ensuring system operation and proper functionality.

- 11. Verify manual operation of the system by depressing the desired functionality button on the SAMS operator control panel, if applicable.
- 12. At any time, should a problem be detected by the SAMS system ECU, an LED will flash on the operator control panel. The flashing LED sequence indicates the error code associated with the detected problem. See the respective system error code identification chart for additional information regarding fault identification and associated

40. APPENDIX D

40.1 System Inclination Sensors



41. APPENDIX E

41.1 SPARTAN – LINK Part Number Cross Reference As of 06/02/2011

SPARTAN #	LINK #		
ASMB-MANIFOLD	H00700EXA		
H00700-ESB	H00700ESB		
H00700-24	H00700-24		
H00701-08	H00701LB		
H15903-C7A	H00710TS		
RD-5715-001	H00700EV		
2220-MM5-002	H00700EB2		
2225-MM5-001	H00700EM		
2225-MM5-004	H00700ES		
2225-MM5-801003	H15903-C7		
2225-MM5-801006	H16171A		
2225-MM5-801009	H00701LA		
2225-MM5-801011	H00700ESC		
2225-MM5-803003	H00700-42		
2609-MM5-001	H00700EN		
2609-MM5-002	H00700ES2		
2609-MM5-003	H00700ER2		
3259-MM5-001	H00700ES20		
2669-MM5-003	H00700ER20		
2669-MM5-004	H00700ET20		
2669-MM5-005	H00700ET25		

42. REVISION TABLE

REV.	ECR	DESCRIPTION	ENG	REV BY	DATE
А		RELEASED			01/03/2006
В	5207	REVISED	СТ	JAL	06/02/2011
С	5621	PG. 13: SWITCH ARROWS TO POINT TO CORRECT INDICATOR	СТ	JAL	03/07/2013
D	6315	UPDATE MANUAL	СТ	DE	07/07/2016
E	6683	ADDED UNITS ON TITLE	СТ	DE	01/19/2017



LINK MANUFACTURING, LTD. 223 15TH ST. NE, SIOUX CENTER, IA 51250 1-800-222-6283 www.linkmfg.com