

ORDERING GUIDE

PROMASTER & PROMASTER CITY



RAMP MODEL RAMP LENGTH BASE UNIT (LBS) WEIGHT CAPACITY (LBS) STORED DEPTH (IN) BASEPLATE WIDTH (IN) BASES UNIT (LBS) BASEPLATE WIDTH (IN) BASES UNIT (LBS) BASEPLATE WIDTH (IN) BASES UNIT (LBS) BASEPLATE WIDTH (IN) BASEPLATE WIDTH (IN) BASEPLATE SPRING ASSIST 24 IN. 30 IN. 36 IN. 47	7 IN. 51 IN.											
PROMASTER CITY STANDARD ROOF												
PROMASTER CITY STANDARD ROOF												
LB20 72 96 1,500 41.5 11.25 41 30-72												
PROMASTER STANDARD & HIGH ROOF												
LSR90 99 157-225 1,500 58.75 9.75 49.5 - 66.5 Yes 30-99 36-99 4	47-99											
LB20 81 103-118 1,500 46.4 11.25 41 - 47 Yes* 30-81 36-81												
LB20 99 120-162 1,500 55.5 11.25 41 - 58 Yes 30-99 36-99 4	47-99											
LT30 119 110-140 1,000 46.5 15 30.25 - 42.25 24-119 30-119 36-119												
PROMASTER HIGH ROOF												

LSR90	108	163-173	1,250	63	9.75	49.5 - 55.5	Yes	30-108	36-108	
LSR90	117	169-179	1,000	67.75	9.75	49.5 - 55.5	Yes	30-117	36-117	
LB20	108	130-142	1,500	59.5	11.25	41 - 47	Yes	30-108	36-108	
LB20	126	156	1,000	68.5	11.25	47	Yes		36-126	
LB20	126	240	2,000	69	11.25	60.75	Yes			51-126

NOTE:~(*)~The 7842A207 (LB20-30-81) is not available with a spring assist.

WARNING: Link products must be professionally installed by a trained technician when being placed into an Electric Vehicle (EV). Electric Vehicles have higher voltage batteries and cables and drilling into Electric Vehicles may cause serious bodily harm and possibly death. Link is not responsible for optional configurations or equipment that restrict the installation of this product in any way. Consult OEM body builder guides for additional installation guidelines.

Phone +1 800 222 6283 | info@linkmfg.com | **linkramps.com**