



### CABMATE® 2483-A000 PARTS LIST

ITEM #	PART #	PART DESCRIPTION	QTY.
1	1102-0022	Spring-Air	2
2	1201-1043	Shock Absorber	2
3	1350-0107	Assembly-Height Control Valve	1
4	1302-5495	Elbow, 1/4tb, 1/8m-NPT, Push-In Swiv Dot	2
5	1302-5498	Branch Tee, 1/4 Tb 1/4 Ptc, Push-In Dot	1
6	1302-5499	Elbow, 1/4 Tb 1/4 Ptc, Push-In Dot	1
7	1302-0090	.25 Airline	1.5 FT.
8	1401-0814	1/4 X 1 3/4 UNC Hex Cap Screw (Grade 5)	2
9	1401-1008	5/16 X 1 UNC Hex Cap Screw (Grade 5)	1
10	1401-1205	3/8 X 5/8 UNC Hex Cap Screw (Grade 5)	2
11	1403-1428	7/16 X 3 1/2 UNF Hex Cap Screw (Grade 5)	2
12	1403-1432	7/16 X 4 UNF Hex Cap Screw (Grade 5)	2
13	1404-1630	1/2 X 3 3/4 UNF Hex Cap Screw (Grade 8)	2
14	1415-1208	3/8 X 1 UNC Sltd Fthd Csk Mach Scr	2
15	1476-0800	1/4 UNC Hex Center Lock Nut (Grade B)	2
16	1476-1000	5/16 UNC Hex Center Lock Nut (Grade B)	1
17	1477-1400	7/16 UNF Hex Center Lock Nut (Grade B)	4
18	1477-1601	1/2 UNF Hex Top Lock Nut (Grade C)	2
19	1485-1200	3/8 Lock Washer	2
20	1500-0071	Bumper-Jounce, 1.25	1
21	1500-0241	Linkage-Valve, Height Control (3.38)	1
22	1500-0435	.25 Corrugated Loom	1.3 FT.
23	2483-1000	Bracket-Mount, Cab	1
24	2483-1001	Bracket-Mount, Crossmember	1
25	2993-2008	Lateral Control Rod	1
26	2991-0026	Kit-Pivot Ball	2